



Respiratory protection must be worn whenever you are working in a hazardous atmosphere. The appropriate respirator will depend on the contaminant(s) to which you are exposed, and the assigned protection factor (APF) required. Required respirators must be NIOSH-approved, and medical evaluation, training, and fit testing must occur before use.

These

Respirator Type	Example	Description	APF

Respirator Type	Example	Description	APF
Self-contained breathing apparatus (SCBA)		<ul style="list-style-type: none"> <li>Provide breathing air independent of the environment.</li> <li>Are to be used when the contaminant has insufficient odor, taste, or irritating warning properties or when the contaminant is of such high concentration or toxicity that an air-purifying respirator is not adequate.</li> <li>While this offers the greatest degree of protection, it is also the most complex; training and practice in its use and maintenance are essential, and it is only for use in emergency situations and oxygen-deficient or Immediately Dangerous to Life or Health (IDLH) atmospheres.</li> <li>All work locations where there are atmospheres that are categorized as IDLH require the use of a full-facepiece, positive-pressure, demand SCBA certified by NIOSH for a minimum service life of 30 minutes or a combination full-facepiece, pressure-demand, supplied-air respirator (SAR) with an auxiliary self-contained air supply.</li> </ul>	<p>Half-face mask (demand mode): 10</p> <p>Full-facepiece (demand mode): 50</p> <p>Full-facepiece (pressure-demand): 10,000</p> <p>Helmet/hood (demand mode): 50</p> <p>Helmet/hood (pressure-demand): 10,000</p>
Emergency escape-use breathing apparatus		<ul style="list-style-type: none"> <li>Self-contained, compressed air apparatus for escape from a contaminated environment (e.g., 10-minute escape).</li> </ul>	N/A

For questi01ref539.9aefE933 rg.7.382 52fEMC 492933 rg3W nBT/TT0 1 Tf1183 (p)2.2 (r)n0 Tw 1t.4 (ea0 1 f118 1t.40.7e